

Form 3200-xxx (R 6/2013)

| Lake Name | County | WBIC | AIS sign? Y N | Secchi (ft or m) | Conductivity (ZM tow if ≥ 99 umhos/cm) |
|-----------------|-------------------------------|--------------------------------------|---------------------|-----------------------------------|--|
| George | Alameda | 1569605 | Y | 07 | 20 |
| Date(s) 8/28 | Data collectors Nancy Ryan | Start time (nearest 15 min) 10:15 | | End time (nearest 15 min) 2:45 | Total collector time (hrs x # collectors) 9 |

STEP 1: Record locations of sampling sites (in decimal degrees). Sampling sites include all public boat landings (BL), 5 targeted sites (TS) and the meander survey sites (MS). List AIS found at each site or record none. Collect a sample of any new AIS found. Collect five new invasive plant specimens, 20 Dreissenids, and 30 of each snail species and label with species, collector, date, lake name, WBIC and sampling site.

[illegible]

*** For lakes/sites not snorkeled, substitute:**

Boat landing site - 15 rake throws and 15 D-net samples OR 30 minutes, whichever comes first
Targeted site - 5 rake throws and 5 D-net samples OR 10 minutes, whichever comes first
50 meander sites - 10 rake throws and 10 D-net samples during meander survey between sampling sites for a total of 50 meander survey sites

*** If lake/site was not snorkeled, indicate why: stained water, turbid water, blue-green bloom, chemical treatment, other (please describe).**

*** Density Ratings**

- 1 - A few plants or invertebrates
- 2 - One or a few plant beds or colonies of invertebrates
- 3 - Many small beds or scattered plants or colonies of invertebrates
- 4 - Dense plant, snail or mussel growth in a whole bay or portion of the lake
- 5 - Dense plant, snail or mussel growth covering most shallow areas

Step 2: Collect Waterflea Tows from 3 sites: the deep hole (DH) and 2 other sites in water deeper than 15 feet (if possible). Submit sample and Water Flea To Monitoring Rept form to Science Services.

| Site | Depth sampled | Method (hor, obliq, vert) | Net diameter (30 or 50 cm) | Ethanol added (Y or N) | Samples combined (Y or N) | Sample sent to, date |
|------|---------------|---------------------------|----------------------------|------------------------|---------------------------|----------------------|
| 1 | 5m | | | | | |
| 2 | 5m | | | | | |

Step 3: Collect Veiliger Tows from 3 sites: the deep hole (DH), outlet site (OS), and or downwind site (DS) in water depth of about 4 meters (if possible). Submit sample and Mussel Veiliger Tow Monitoring Report form to Science Service.

| Site | Depth sampled | Net diameter (30 or 50 cm) | Ethanol added (Y or N) | Samples combined (Y or N) | Sample sent to, date |
|------|---------------|----------------------------|------------------------|---------------------------|----------------------|
| | | | | | |
| | | | | | |
| | | | | | |



Step 4: Were plant voucher specimens submitted? Yes No (circle) If yes, where? (circle) Freckmann Herbarium, Other _____

Step 5: Were snail voucher specimens submitted (separate into Chinese, banded, all others)? Yes No (circle) If yes, where? (circle) UW La Crosse, or Other _____

Step 6: Data was entered into SWIMS on 9/3/13 by Ryan Plotnik

Step 7: Data was proofed on 10/23/13 by Janice Stellegger

Notes:



1569600 George Lake